




# Cynap Pure Pro


## Quick Start Guide

# INITIAL SETUP/INSTALLATION



1. Connect HDMI cable between Cynap Pure Pro and display monitor or projector
2. Connect your network for a corporate network integration
3. Optional (only for touchscreen users): Connect USB cable between Cynap Pure Pro and display monitor to use touch functionality
4. Plug in power supply
5. Power on the device
6. Start screen sharing

# START SCREEN SHARING




## All Apple, Windows, Android and Chrome OS devices

Connect to the Cynap Pure Pro access point, either by scanning the QR code or connecting manually. Share your screen using either AirPlay, Chromecast or Miracast, depending on your device.

**Windows**  
Press the keys  
  
on the keyboard

**Apple**  
Click on  
  
on the menu bar

# START HYBRID MEETING (BYOM)



1. To start a Hybrid Meeting (BYOM) – Download vSolution App (free download) onto your laptop (**[wolfvision.com/en/support/vsolution-app](http://wolfvision.com/en/support/vsolution-app)**)
2. Open vSolution App on your Laptop and connect to the Cynap Pure Pro shown in the Device List.
3. Select "Connect Room Audio/Video" in the Mode Selector
4. The Room Devices will now be visible in the audio-/video settings of your conferencing app (MS Teams, Zoom, Google Meet, etc.) as Room Audio / Video

## OPTIONAL ACCESSORY



### **Do you need a remote control?**

WolfVision introduces green initiatives wherever possible in order to minimise the company's environmental footprint.

In view of this, and to avoid unnecessary wastage, a remote control is not delivered with this model. However, for customers that need a remote control they are available to purchase on request.

Please contact your WolfVision partner or local sales representative for more information.

## More Information and Video Guides in our Quick Start Area



Scan the QR code or visit our website for more information  
[pure-pro.cynap.net/support](https://pure-pro.cynap.net/support)