

vSolution Cynap Core by WolfVision


Introduction

Cynap Core by WolfVision® delivers an all-in-one collaboration and presentation solution, featuring BYOD, streaming to vSolution Cynap systems, and a document and media player, with support for up to FullHD resolution.

Hardware Connection

Make all necessary connections according to the following illustrations.
Plug in the power cord as the last step.
Power on the equipment.

Operating for the first time

When Cynap is switched on, all settings can be set in the password protected settings of the graphical user interface (GUI). Access the GUI by using a web browser on your connected PC or tablet (input the IP address), by using the optional remote control, or by using connected USB mouse and keyboard.
Push the  symbol/button at the right edge to open the toolbox and select Settings.

Typical Setup

